

Congratulations on your purchase of an Arnett® air suspension product. We at Arnett Incorporated are proud to offer a high quality product at the industry's most competitive pricing. Thank you for your confidence in us and our product.

Proper installation is essential to experience and appreciate the benefits of this system. Please take a moment to review these installation instructions before you begin to install these components on your vehicle. The removal and installation of air suspension products should only be performed by a fully qualified, ASE Certified, professional.

It is equally important to be aware of all necessary safety measures while installing your new Air Suspension System. This includes proper lifting and immobilizing of the vehicle and isolation of any stored energy to prevent personal injury or property damage.

"Engineered to Ride, Built to Last®"



WARNING: *The air suspension system is under pressure (up to 10 bar, or 150 lbf/in). Verify pressure has been relieved and disconnect power to the air suspension system prior to disassembly. Do not allow dirt or grease to enter the system. Always wear standard hand, ear, and eye protection when servicing the air suspension system.*

Arnett® is committed to the quality of its products. If you have a question or problem with any Arnett product, please contact Arnett by calling [800-251-8993](tel:800-251-8993) during normal business hours or email techassistance@arnottinc.com.

GENERAL INFORMATION:

Reading this manual signifies your agreement to the terms of the general release, waiver of liability, and hold harmless agreement, the full text of which is available at www.arnottinc.com.

- Not to be stored below 5°F (-15°C) or above 122°F (50°C).
- Avoid damage to air lines and cables.
- Removal and installation is only to be performed by fully qualified personnel.
- Use car manufacturer's diagnostic software.

CAUTION: *Damage to the vehicle and air suspension system can be incurred if work is carried out in a manner other than specified in the instructions or in a different sequence.*



To avoid the possibility of short circuits while working with electric components consult your owner's manual on how to disconnect your battery.



Consult your vehicle owner's manual, service manual, or car dealer for the correct jacking points on your vehicle and for additional care, safety and maintenance instructions. Under no circumstances should any work be completed underneath the vehicle if it is not adequately supported, as serious injuries and death can occur.

AIR SPRING/AIR SUSPENSION COMPRESSOR REMOVAL

1. Lift vehicle and remove both rear wheels.
2. Locate the air compressor centered behind the rear axle.
3. Refer to the vehicle's shop manual for proper removal instructions or consult your local dealership for further assistance on how to disconnect and/or remove the air suspension compressor. Removal is not required, but disconnection, is to avoid suspension messages.
4. Rotate the rear air springs and pull downward to remove them from the axle. The air springs are held from turning with a plastic clip on top of the air spring. You may have to hold the plastic clip down while rotating the air spring to free it from the upper spring seat.
5. Disconnect the air line from the air springs by pressing down on the steel fitting while pulling outward on the air line.
6. Carefully remove air spring from the vehicle.
7. Seal off hose to prevent dirt or grease from entering system.
8. Remove both lower shock bolts. Allow axle to hang free unsupported. This will give you extra clearance for the coil spring.

COIL SPRING INSTALLATION




Tighten all nuts and bolts to manufacturer's specifications during the installation process.

NOTE:

Tie the wires and air hose back away from any hot or moving parts.

1. Install the coil springs onto the rear axle.
2. Using a floor jack, raise the rear axle.
3. Install the lower shock absorber retaining nut and bolt to the rear axle.
4. Remove the rear axle support.
5. Replace wheels.
6. Remove all safety stands and lower vehicle.

REMOVAL DIAGRAM



INSTALLATION DIAGRAM

