

FRONT

Cadillac Strut

Installation Guide for Arnott Kit #

93-CF

96-CF

97-CF



Copyright © 2004 Arnott Inc. All Rights Reserved.


Arnott Inc.

Front Cadillac Strut Kit Installation Guide

1. Raise vehicle with proper lifting equipment. The tires must be off the ground. Suspension must be fully down with no load. **ALWAYS USE EXTREME CAUTION WHEN LIFTING VEHICLE!** (Refer to shop manual for lifting instructions)
2. Remove front wheel(s).



3. Unbolt the 2 side brackets from the strut. ↑
(These brackets hold the brake lines and other cables)



4. Remove the position sensor from upper and lower ball studs. ↑



5. Remove nut from stabilizer link ↑



6. Remove stabilizer link from strut. ↑



7. Remove strut damper solenoid cable from mounting brackets. ↑



8. Unplug the strut damper solenoid. ↑



9. Remove the two nuts at the bottom of the strut. ↑



10. Remove the two strut-to-knuckle bolts. ↑



11. Knuckle will fall away from strut. ↑



13. Remove 3 nuts attaching top of strut assembly to body. ↑



14. Remove old strut from vehicle. ↑

Notice: Before you can install the new strut, you must first remove the coil spring with a spring compressor. Coil springs can be very dangerous. Make sure you follow all of the safety guidelines illustrated with the spring compressor.

15. Replace 3 nuts attaching top of strut assembly to body. (Reverse step 13)

16. Replace the two strut-to-knuckle bolts. (Reverse steps 9 and 10)

17. Plug in the new strut solenoid and hook the cable back to the mounting brackets. (Reverse steps 7 and 9)

18. Bolt stabilizer link to strut. (Reverse steps 5 and 6)

19. Replace the position sensor back to the upper and lower ball studs. (Reverse step 4)

20. Replace the brackets to the bottom of the strut. (Reverse step 3)

21. Replace wheel and lower suspension.

Notice: Wheel alignment is highly recommended. Changing your front struts will throw your alignment out of adjustment causing premature tire wear.

Thank you for purchasing an Arnott suspension product.