




Hummer H2 Compressor Hose & CPU Install Guide




1. Locate and unplug your ECU module from your old compressor. The module is located to the side of your compressor assembly.




2. After unplugging the module, slide it forward and unclip it from the old compressor assembly. Install your old module in reverse order onto the new unit.



3. Remove the shipping plugs from the new compressor. There are 3 black caps over the exit ports, and 2 red caps over the intakes.



4. Install the 2 smaller hose assembly onto the valve block and tire inflator exit port.



5. Install the single small hose in right side of the valve block. This hose has a red mark on the end.



6. Install the dual intake hose assembly into the ports on the top side of the compressor.