



## FRONT OF CONTROLLER



Pressing both Increase or Decrease buttons at once syncs the pressures, then inflates or deflates both sides simultaneously.

## BACK OF CONTROLLER




# EXPLANATION DISPLAY

Pressure in Air Spring Value

Connected to Console

Connected to Phone





Selected Preset Function  
(Colored When Selected & Adjusting)

Target & Current  
Pressure (When  
Preset Selected)

Selected Corner  
(Colored When  
Operating)

**Save Preferred Value:** Manually adjust both pressures.  
Hold relevant button (1, 2, or 3) for 3 seconds. Confirm after.



Use the Left Up & Down  
Buttons to Scroll Through  
the Menu

Open the Menu by Pressing the 2 Left Buttons  
& Hold for 3 Seconds