



ATTENTION




**INSTALLATION OF THIS AIR SUSPENSION COMPRESSOR
REQUIRES THE REPLACEMENT OF THE COMPRESSOR RELAY.**

**FAILURE TO REPLACE THE OE RELAY WITH THE UNIT PROVIDED IN
THIS KIT CAN CAUSE DAMAGE AND/OR VOID WARRANTY.**

PLEASE REFER TO YOUR VEHICLES SHOP MANUAL OR CONSULT YOUR LOCAL DEALERSHIP FOR
ADDITIONAL INFORMATION AND PROPER PROCEDURES FOR REPLACING YOUR AIR SUSPENSION
COMPRESSOR RELAY.


P-3220/P-3729



BMW 5 SERIES (E61)

Relay located in the trunk of the vehicle under the spare
tire compartment.


P-4341




BMW X5 (F15)/X6 (F16)

Relay located in the trunk of the vehicle on the right side.

P-2985/P-3818



BMW 5 SERIES GT (F07)
Relay located in the trunk of the vehicle on the right side.



BMW 5 SERIES WAGON (F11)
Relay located in the trunk of the vehicle beneath the floor.



BMW 7 SERIES (F01/02/04)
Relay located in the trunk of the vehicle on the right side.

Arnott™

Suspension Products

Arnott US Business Office:

www.arnottinc.com

100 Sea Ray Drive
Merritt Island, FL 32953

Call: 800.251.8993

321.868.3016

Fax: 321.868.3703

Email: techassistance@arnottinc.com

Arnott Europe Business Office:

www.arnotteurope.com

Docterskampstraat 1E/1F, 3
5222 AM 's-Hertogenbosch (NL)

NL Phone: +31 73 7850 580

DE Phone: +31 85 2087 438

UK Phone: +44 203 3186 124

BE Phone: +32 258 846 90


ES Phone: +34 91 901 10 56

FR Phone: +32 78 48 46 93


Email: info@arnotteurope.com




Air Springs




Struts




Shocks




Compressors




Dryers



Coil Spring
Conversion Kits



Valve Blocks



Ride Height
Sensors