

REMANUFACTURED AIR STRUT SERVICE BULLETIN



ATTENTION



UPON VISUAL INSPECTION OF YOUR AIR STRUT, IT MAY APPEAR THAT THE AIR STRUT IS BENT. THIS IS COMPLETELY NORMAL AND THE AIR STRUT WILL STRAIGHTEN OUT WHEN PROPERLY INSTALLED ON THE VEHICLE.

DO NOT RETURN AIR STRUT DUE TO THE VISUAL APPEARANCE OF IT BEING BENT.

W166



THIS IS NORMAL
(AS-3060, AS-3061)

W166



THIS IS NORMAL
(AS-3085, AS-3086)


Arnott® is committed to the quality of its products. If you have a question or problem with any Arnott product, please contact Arnott by calling **800-251-8993** during normal business hours or email techassistance@arnottinc.com. (In the EU please call +31 (0)73 7850 580 or email info@arnotteurope.com).

REMOVAL



Prior to inserting the existing air line into the new air fitting you will need to remove the old original equipment air line fitting.

NOTE: SCRATCHES AND/OR DEEP CUTS IN THE AIR LINE CAN RESULT IN POSSIBLE LEAKS. INSPECT THE AIR LINE BEFORE INSERTION. AIR LINE NEEDS TO BE REPLACED IF DAMAGED.



#1

OE AIR LINE FITTING

#2

SLIDE THE THREADED PORTION UP THE LINE AND SPREAD THE COLLET OPEN TO REMOVE

#3

SLIDE THE AIR FITTING OFF OF THE AIR LINE

#4

AIR LINE IS READY FOR INSTALLATION

INSTALLATION - USING THE NEW AIR LINE FITTING PROVIDED IN THE KIT



#1

USE A WRENCH TO LOOSEN THREADED PLUG

#2


REMOVE THREADED PLUG AND DISCARD

#3

THREAD THE INCLUDED AIR LINE FITTING INTO THE VALVE

#4

TIGHTEN FITTING TO APPROX. 2NM (18 IN-LBS/1.5 FT-LBS)



#5

REMOVE AND DISPOSE OF THE SHIPPING PIN

#6

INSERT AIR LINE INTO THE AIR LINE FITTING UNTIL IT STOPS

#7

AIR LINE INSERTED

#8

GENTLY PULL ON AIR LINE TO CONFIRM IT IS FULLY SECURED BY THE AIR LINE FITTING